


ACTIVACION DE VOLTAJES DE BB IPHONE X

ENTRADAS




Giño Morales

ACTIVACION DE VOLTAJES DE BB IPHONE X



SALIDAS



RFFE1: LATCP, UATCP, LBPA, MHBPA, GSMPT, TDDPA, ET, XCVR0, XCVR1, DSM, GPOLAT, JLAT1
 RFFE2: XCVR0, XCVR1, MHLN, LBLN, GPOUAT, JUAT1
 RFFE VIO 1V8: MHLN, LBLN, XCVR0, XCVR1, TDDPA, LBPA, MHBPA, ET, GSMPT, UATCP, LATCP



Giño Morales